

# DuPont™ Kalrez® 4079

For Semiconductor Applications

Technical Information—Rev. 4, July 2010

## Product Description

DuPont™ Kalrez® 4079 perfluoroelastomer parts are a black, low compression set product for use in many dry and wet semiconductor process environments. It has excellent chemical resistance, good mechanical properties and outstanding thermal stability. Kalrez® 4079 exhibits low weight loss in reactive plasmas and has good response to temperature cycling effects. It is not recommended for use in amines. A maximum continuous service temperature of 316 °C is suggested. Short excursions to higher temperatures are also possible. Ultrapure post-cleaning and packaging is optional.

## Performance Features/Benefits

- Excellent thermal stability
- Excellent chemical resistance
- Excellent compression set resistance
- Good response to temperature cycling effects

### Typical O-ring Compression Set Performance\* (70 hr data)

Material Tested, % C/S at	204 °C	250 °C	300 °C
Kalrez® 4079	37	41	45
Competitive FFKM A2	43	100	Sample Failed

\* ASTM D395B and D1414 (AS568 K214 O-ring test specimens)

## Typical Physical Properties<sup>1</sup>

Hardness Shore A, (pellet) <sup>2</sup>	75
Hardness Shore M, (O-ring) <sup>3</sup>	83
100% Modulus <sup>4</sup> , MPa	7.24
Tensile Strength at Break <sup>4</sup> , MPa	16.88
Elongation at Break <sup>4</sup> , %	150
Compression Set <sup>5</sup> , % 70 hr at 204 °C, %	25
Maximum Continuous Service Temperature <sup>6</sup> , °C	316

<sup>1</sup>Not to be used for specification purposes

<sup>2</sup>ASTM D2240 (pellet test specimens)

<sup>3</sup>ASTM D2240 and ASTM D1414 (AS568 K214 O-ring test specimens)

<sup>4</sup>ASTM D412 (dumbbell test specimens)

<sup>5</sup>ASTM D395B (pellet test specimens)

<sup>6</sup>DuPont proprietary test method

## Kalrez® Offers Excellent Resistance to Chemical Attack

For many applications, low volume swell of elastomers is critical for proper equipment operation. Excessive swell may cause permanent seal failure due to equipment hang-up, extrusion, etc. While other physical property testing may be needed to adequately define product performance in a particular application, volume swell is an excellent indicator of resistance to chemical attack. A summary of the internal and external compatibility tests performed to determine the volume swell of Kalrez® 4079UP in various semiconductor wet process environments is provided in the table on the following page.



The miracles of science™

## Volume Swell<sup>1</sup>, %

Immersion Chemistry	Exposure Conditions	DuPont™ Kalrez® 4079UP <sup>2</sup>
UPDI Water	85 °C, 30 days	2.3
Piranha	25 °C, 30 days	0.1
SC-1	25 °C, 30 days	1.1
SC-2	25 °C, 30 days	0.1
49% HF	25 °C, 30 days	0.6
Sulfuric Acid	120 °C, 30 days	0.8
Nitric Acid	85 °C, 7 days	1.5
n-Methylpyrrolidone	85 °C, 7 days	2.4

<sup>1</sup> The volume swell values above should be used as an approximate indicator of relative compatibility performance. Generally <10% volume swell is desirable.

<sup>2</sup> Testing performed on ultrapure-cleaned AS568 K214 O-ring test specimens.

---

Visit us at [kalrez.dupont.com](http://kalrez.dupont.com) or [vespel.dupont.com](http://vespel.dupont.com)

---

Contact DuPont at the following regional locations:

**North America**  
800-222-8377

**Latin America**  
+0800 17 17 15

**Europe, Middle East, Africa**  
+41 22 717 51 11

**Greater China**  
+86-400-8851-888

**ASEAN**  
+65-6586-3688

**Japan**  
+81-3-5521-8484

---

The information set forth herein is furnished free of charge and is based on technical data that DuPont believes to be reliable and falls within the normal range of properties. It is intended for use by persons having technical skill, at their own discretion and risk. This data should not be used to establish specification limits nor used alone as the basis of design. Handling precaution information is given with the understanding that those using it will satisfy themselves that their particular conditions of use present no health or safety hazards. Since conditions of product use and disposal are outside our control, we make no warranties, express or implied, and assume no liability in connection with any use of this information. As with any product, evaluation under end-use conditions prior to specification is essential. Nothing herein is to be taken as a license to operate or a recommendation to infringe on patents.

**Caution:** Do not use in medical applications involving permanent implantation in the human body. For other medical applications, discuss with your DuPont customer service representative and read Medical Caution Statement H-50103-3.

Copyright © 2010 DuPont. The DuPont Oval Logo, DuPont™, The miracles of science™, Kalrez®, and Vespel® are trademarks or registered trademarks of E.I. du Pont de Nemours and Company or its affiliates. All rights reserved.

(06/05) Reference No. KZE-A10299-00-D0710



*The miracles of science™*